




### Jumper Functions

- JP-1 X Axis Power
- JP-2 Y Axis Power
- JP-3 Z Axis Power
- JP-4 A Axis Power
- JP-5 Input Pull Up Resistors Enable
- JP-6 Voltage Regulation Isolation
- JP-7 Input Enable

### PBX Header Pin Diagram



- E-Stop**
- X-Limit**
- Y-Limit**
- Z-Limit**
- Unused**



# Wiring for Limit Switches, E-Stop at PBX-RF Controller

